

SPARE ROBOT BATTERY



BRAND: ROBOTEX INC

The AVATAR III's battery lasts about 4-5 hours with normal use. The Spare Robot Battery is quickly and easily exchanges for a dead robot battery, giving the operator double the run time. It takes about the same time to recharge a battery that it takes to run one down, so there can be almost unlimited use.

For more information please contact:

AARDVARK 1935 PUDDINGSTONE DRIVE, LA VERNE, CA 91750

P (800) 997 3773 **P** (909) 451 6100 **F** (909) 392 3823

AARDVARKTACTICAL.COM

